

QUARTZ

Care & Maintenance



Once in service...

Your new quartz worksurface is a modern material which requires little day to day care.

Clean the surfaces regularly with water containing soap or a mild detergent and a soft cloth or sponge. Rinse off surfaces with clean water. Polish dry with a soft cloth. Alternatively use the 'E Cloth' surface cleaning system for a consistent, smear free finish every time.

Tougher stains can be removed by using a product such as Cif Actifizz with in conjunction with a plastic scouring pad.

Avoid use of abrasive cleaning materials: scouring powders, steel wool, metal brushes, etc.

Never use bleaches or chlorine based cleaners, acids, photographic development liquid, alkalis (caustic soda) or concentrated disinfectants on quartz surfaces. If any of these come into contact with the material, clean them off immediately, otherwise surface damage may occur.

Do not allow surface deposits to build up on surfaces, e.g. powder detergents, mineral deposits and salts.

Strongly coloured foodstuffs, such as blackcurrant and beetroot, can be difficult to remove from quartz surfaces, especially light colours. Use a cleaner such as Cif Actifizz and a plastic scouring pad.

Always use pan stands and trivets to protect the surface from hot, rough and wet pots, pans and utensils. Direct contact from iron, steel, ceramic and copper vessels can scratch and stain the surface.

Always use cutting boards to chop and slice food upon. Never cut directly onto the quartz surfaces.

Never stand, sit or put heavy weights on the worktop, especially around sinks and hobs where the material may be weaker.